

CROSS REFERENCE

APOLLO		
P-1200 SERIES	BLACK	HP 51626A HP#26
APOLLO P-1200 SERIES	COLOR	HP 51625A HP#25
APOLLO P-2100U SERIES	BLACK	HP C6614 HP #20
APOLLO P-2100U SERIES	COLOR	HP 51649A HP#49
APOLLO P-2100U SERIES	PHOTO	HP C1816A HP#16
APOLLO P-2200 SERIES	BLACK	HP C6614A/D/N HP #20
APOLLO P-2200 SERIES	COLOR	HP 51649A HP#49
APOLLO P-2200 SERIES	PHOTO	HP C1816A HP#16
APPLE		
APPLE COLOR PRINTER M6901G/A	BLACK	CANON BJI-643B
APPLE COLOR PRINTER M6902G/A	YELLOW	CANON BJI-643Y
APPLE COLOR PRINTER M6903G/A	MAGENTA	CANON BJI-643M
APPLE COLOR PRINTER M6904G/A	CYAN	CANON BJI-643C
APPLE COLOR STYLEWRITER 4100	BLACK	HP 51629A HP#29
APPLE COLOR STYLEWRITER 4100	COLOR	HP 51649A HP#49
APPLE COLOR STYLEWRITER 4100	PHOTO	HP C1816A HP#16
APPLE COLOR STYLEWRITER 4500	BLACK	HP 51629A HP#29
APPLE COLOR STYLEWRITER 4500	COLOR	HP 51649A HP#49
APPLE COLOR STYLEWRITER 4500	PHOTO	HP C1816A HP#16
APPLE COLOR STYLEWRITER 6500	BLACK	HP 51645A HP#45
APPLE COLOR STYLEWRITER 6500	COLOR	HP 51641A HP#41
APPLE COLOR STYLEWRITER PRO	BLACK	CANON BJI-201B
APPLE COLOR STYLEWRITER PRO	CYAN	CANON BJI-201C
APPLE COLOR STYLEWRITER PRO	MAGENTA	CANON BJI-201M
APPLE COLOR STYLEWRITER PRO	YELLOW	CANON BJI-201Y
APPLE DESKWRITER	BLACK	HP51626A / G HP#26
APPLE PORTABLE STYLEWRITER	BLACK	CANON BC-02
APPLE STYLEWRITER	BLACK	CANON BC-02
APPLE STYLEWRITER 1200	BLACK	CANON BC-02
APPLE STYLEWRITER 1500	BLACK	CANON BC-02
APPLE STYLEWRITER 1500	COLOR	CANON BC-05
APPLE STYLEWRITER 2200	COLOR	CANON BCI-11C
APPLE STYLEWRITER 2200	LARGE BLACK	CANON BCI-10
APPLE STYLEWRITER 2200	SMALL BLACK	CANON BCI-11B
APPLE STYLEWRITER 2400	LARGE BLACK	CANON BC-20
APPLE STYLEWRITER 2400	BLACK TANK	CANON BCI-21B
APPLE STYLEWRITER 2400	COLOR TANK	CANON BCI-21C
APPLE STYLEWRITER 2500	LARGE BLACK	CANON BC-20
APPLE STYLEWRITER 2500	BLACK TANK	CANON BCI-21B
APPLE STYLEWRITER 2500	COLOR TANK	CANON BCI-21C
APPLE STYLEWRITER 2500	PHOTO	CANON BC-22E
APPLE STYLEWRITER I	BLACK	CANON BC-02
APPLE STYLEWRITER II	BLACK	CANON BC-02
BROTHER		
BROTHER HJ400	BLACK	CANON BC-02
BROTHER DP-80	BLACK	LEXMARK 1380620 / 13620HC / 13400HC
BROTHER DP-80	COLOR	LEXMARK 1380619 / 13619HC
BROTHER ENSEMBLE	BLACK	LEXMARK 1380620 / 13620HC / 13400HC
BROTHER GW 70I, 80I	BLACK	CANON BC-02
BROTHER HC-2500	BLACK	LC01BK
BROTHER HC-2500	CYAN	LC01C
BROTHER HC-2500	MAGENTA	LC01M
BROTHER HC-2500	YELLOW	LC01Y
BROTHER HJ-770	BLACK	CANON BJI-642B
BROTHER HJ 100	BLACK	CANON BC-02
BROTHER HJ 400	BLACK	CANON BC-02
BROTHER HJ 770	BLACK	CANON BJI-642B
BROTHER L SERIES	BLACK	CANON BC-02
BROTHER MFC7000FC	BLACK	LC01BK
BROTHER MFC7000FC	CYAN	LC01C

BROTHER MFC7000FC	MAGENTA	LC01M
BROTHER MFC7000FC	YELLOW	LC01Y
BROTHER MFC7050C	BLACK	LC11BK
BROTHER MFC7050C	COLOR	LC11CL
BROTHER MFC7150C / 7160C	BLACK	LC02BK
BROTHER MFC7150C / 7160C	YELLOW	LC02Y
BROTHER MFC7150C / 7160C	CYAN	LC02C
BROTHER MFC7150C / 7160C	MAGENTA	LC02M
BROTHER MFC7200FC	BLACK	LC01BK
BROTHER MFC7200FC	CYAN	LC01C
BROTHER MFC7200FC	MAGENTA	LC01M
BROTHER MFC7200FC	YELLOW	LC01Y
BROTHER MFC9100	BLACK	LC02BK
BROTHER MFC9100	YELLOW	LC02Y
BROTHER MFC9100	CYAN	LC02C
BROTHER MFC9100	MAGENTA	LC02M
BROTHER MP21C MOBILE INKJET	BLACK / CYAN	LC03BC
BROTHER MP21C MOBILE INKJET	MAGENTA / YELLOW	LC03MY
BROTHER MP21CDX MOBILE INKJET	BLACK / CYAN	LC03BC
BROTHER MP21CDX MOBILE INKJET	MAGENTA / YELLOW	LC03MY
BROTHER PDP300C/C50CJ	BLACK	IN-700
BROTHER PDP300C/C50CJ	COLOR	IN-710C
BROTHER WP7000J	BLACK	CANON BC-02
BROTHER WP7500J	BLACK	CANON BC-02
CANON		
CANON B550	BLACK	CANON BX-3
CANON BJ NOTE	BLACK	BCI-10
CANON BJ NOTE	COLOR	BCI-11C
CANON BJ-100	BLACK	BC-02
CANON BJ10-10EX	BLACK	BC-02
CANON BJ-10E	BLACK	BC-02
CANON BJ-10SX	BLACK	BC-02
CANON BJ-10V	BLACK	BC-02
CANON BJ-15V	BLACK	BC-02
CANON BJ-20	BLACK	BC-02
CANON BJ-30	BLACK	BCI-10
CANON BJ-300	BLACK	BJI-642B
CANON BJ-30V	BLACK	BCI-10
CANON BJ-330	BLACK	BJI-642B
CANON BJ-35	BLACK	BCI-10
CANON BJ-35	COLOR	BCI-11C
CANON BJ35V	BLACK	BCI-10
CANON BJ35V	COLOR	BCI-11C
CANON BJ-5	BLACK	BC-02
CANON BJC 1000	BLACK	BC-02
CANON BJC 1000 SERIES	COLOR	BC-05
CANON BJC 1000 SERIES	PHOTO	BC-06
CANON BJC 200 SERIES	BLACK	BC-02
CANON BJC 200 SERIES	COLOR	BC-05
CANON BJC 200 SERIES	PHOTO	BC-06
CANON BJC 2000 / 2100 / 2120	LARGE BLACK	BC-20
CANON BJC 2000 / 2100 / 2120	BLACK TANK	BCI-21B
CANON BJC 2000 / 2100 / 2120	COLOR TANK	BCI-21C
CANON BJC 2000 / 2100 / 2120	PHOTO	BC-22E
CANON BJC 3000	BLACK	BCI-3EBK
CANON BJC 3000	CYAN	BCI-3EC
CANON BJC 3000	MAGENTA	BCI-3EM
CANON BJC 3000	YELLOW	BCI-3EY
CANON BJC 3000	PHOTO BLACK	BCI-3PBK
CANON BJC 3000	PHOTO CYAN	BCI-3PC
CANON BJC 3000	PHOTO MAGENTA	BCI-3PM
CANON BJC S400 & S450 SERIES	BLACK	BCI-3EBK
CANON BJC S400 & S450 SERIES	CYAN	BCI-3EC
CANON BJC S400 & S450 SERIES	MAGENTA	BCI-3EM

CANON BJC S400 & S450 SERIES	YELLOW	BCI-3EY
CANON BJC 4000	LARGE BLACK	BC-20
CANON BJC 4000	BLACK TANK	BCI-21B
CANON BJC 4000	COLOR TANK	BCI-21C
CANON BJC 4000	PHOTO	BC-22E
CANON BJC 4100	LARGE BLACK	BC-20
CANON BJC 4100	BLACK TANK	BCI-21B
CANON BJC 4100	COLOR TANK	BCI-21C
CANON BJC 4100	PHOTO	BC-22E
CANON BJC 4200	LARGE BLACK	BC-20
CANON BJC 4200	BLACK TANK	BCI-21B
CANON BJC 4200	COLOR TANK	BCI-21C
CANON BJC 4200	PHOTO	BC-22E
CANON BJC 4300	LARGE BLACK	BC-20
CANON BJC 4300	BLACK TANK	BCI-21B
CANON BJC 4300	COLOR TANK	BCI-21C
CANON BJC 4300	PHOTO	BC-22E
CANON BJC 4400	LARGE BLACK	BC-20
CANON BJC 4400	BLACK TANK	BCI-21B
CANON BJC 4400	COLOR TANK	BCI-21C
CANON BJC 4400	PHOTO	BC-22E
CANON BJC 4550	LARGE BLACK	BC-20
CANON BJC 4550	BLACK TANK	BCI-21B
CANON BJC 4550	COLOR TANK	BCI-21C
CANON BJC 4550	PHOTO	BC-22E
CANON BJC 5000	LARGE BLACK	BC-23
CANON BJC 5000	BLACK TANK	BCI-21B
CANON BJC 5000	COLOR TANK	BCI-21C
CANON BJC 5000	PHOTO	BC-22E
CANON BJC 5100	LARGE BLACK	BC-23
CANON BJC 5100	BLACK TANK	BCI-21B
CANON BJC 5100	COLOR TANK	BCI-21C
CANON BJC 5100	PHOTO	BC-22E
CANON BJC 600 SERIES	BLACK	BJI-201B
CANON BJC 600 SERIES	CYAN	BJI-201C
CANON BJC 600 SERIES	MAGENTA	BJI-201M
CANON BJC 600 SERIES	YELLOW	BJI-201Y
CANON BJC 6000	BLACK	BCI-3BK
CANON BJC 6000	CYAN	BCI-3C
CANON BJC 6000	MAGENTA	BCI-3M
CANON BJC 6000	YELLOW	BCI-3Y
CANON BJC 6000	PHOTO BLACK	BCI-3PBK
CANON BJC 6000	PHOTO CYAN	BCI-3PC
CANON BJC 6000	PHOTO MAGENTA	BCI-3PM
CANON BJC 7000	BLACK	BC-60 REQUIRES OLD PRINTHEAD
CANON BJC 7000	COLOR	BC-61/BCI-61
CANON BJC 7000	PHOTO	BC-62/BCI-62
CANON BJC 700J	BLACK	BC-60 REQUIRES OLD PRINTHEAD
CANON BJC 700J	COLOR	BC-61/BCI-61
CANON BJC 700J	PHOTO	BC-62/BCI-62
CANON BJC 800 SERIES	BLACK	BJI-643B
CANON BJC 800 SERIES	CYAN	BJI-643C
CANON BJC 800 SERIES	MAGENTA	BJI-643M
CANON BJC 800 SERIES	YELLOW	BJI-643Y
CANON BJC 8000	BLACK	BC-60
CANON BJC 8000	COLOR	BC-61/BCI-61
CANON BJC 8000	PHOTO	BC-62/BCI-62
CANON BJC 8200	BLACK	BCI-6BK
CANON BJC 8200	CYAN	BCI-6C
CANON BJC 8200	MAGENTA	BCI-6M
CANON BJC 8200	PHOTO CYAN	BCI-6PC
CANON BJC 8200	PHOTO MAGENTA	BCI-6PM
CANON BJC 8200	YELLOW	BCI-6Y
CANON BJC 8500	BLACK	BCI-8BK

CANON BJC 8500	PHOTO BLACK	BCI-8PBK
CANON BJC 8500	CYAN	BCI-8C
CANON BJC 8500	MAGENTA	BCI-8M
CANON BJC 8500	PHOTO CYAN	BCI-8PC
CANON BJC 8500	PHOTO MAGENTA	BCI-8PM
CANON BJC 8500	YELLOW	BCI-8Y
CANON BJC-150	BLACK	BC-02
CANON BJC-150	COLOR	BC-05
CANON BJC-50	LARGE BLACK	BCI-10
CANON BJC-50	BLACK	BCI-11B
CANON BJC-50	COLOR	BCI-11C
CANON BJC-70	LARGE BLACK	BCI-10
CANON BJC-70	BLACK	BCI-11B
CANON BJC-70	COLOR	BCI-11B
CANON BJC-80	LARGE BLACK	BCI-10
CANON BJC-80	BLACK	BCI-11B
CANON BJC-80	COLOR	BCI-11C
CANON BJC-85	LARGE BLACK	BCI-10
CANON BJC-85	BLACK	BCI-11B
CANON BJC-85	COLOR	BCI-11C
CANON BJP-C80	BLACK	BJI-643B
CANON BJP-C80	CYAN	BJI-643C
CANON BJP-C80	MAGENTA	BJI-643M
CANON BJP-C80	YELLOW	BJI-643Y
CANON C3500	LARGE BLACK	BC-20
CANON C3500	BLACK TANK	BCI-21B
CANON C3500	COLOR TANK	BCI-21C
CANON C3500	PHOTO	BC-22E
CANON C5500	LARGE BLACK	BC-20
CANON C5500	BLACK TANK	BCI-21B
CANON C5500	COLOR TANK	BCI-21C
CANON C5500	PHOTO	BC-22E
CANON FAX B100	BLACK	BC-02
CANON FAX B140,150,160,170,190	BLACK	BC-02
CANON FAX B200	BLACK	BC-02
CANON FAX B220	BLACK	BC-02
CANON FAX B340,360	BLACK	BC-02
CANON FAX B405	BLACK	BC-02
CANON FAX B405	BLACK	BC-02
CANON FAX B540	BLACK	BX-3
CANON FAX B550	BLACK	BX-3
CANON FAX B60,70	BLACK	BC-02
CANON FAX B600	BLACK	BX-3
CANON FAX B640	BLACK	BX-3
CANON MONOPRINTER	BLACK	BX-3
CANON MULTIPASS 800	BLACK	BX-3
CANON MULTIPASS C2500	LARGE BLACK	BC-20
CANON MULTIPASS C2500	BLACK TANK	BCI-21B
CANON MULTIPASS C2500	COLOR TANK	BCI-21C
CANON MULTIPASS C-30	LARGE BLACK	BC-20
CANON MULTIPASS C-30	BLACK TANK	BCI-21B
CANON MULTIPASS C-30	COLOR TANK	BCI-21C
CANON MULTIPASS C3000	LARGE BLACK	BC-20
CANON MULTIPASS C3000	BLACK TANK	BCI-21B
CANON MULTIPASS C3000	COLOR TANK	BCI-21C
CANON MULTIPASS C3000	PHOTO	BC-22E
CANON MULTIPASS C3500	LARGE BLACK	BC-20
CANON MULTIPASS C3500	BLACK TANK	BCI-21B
CANON MULTIPASS C3500	COLOR TANK	BCI-21C
CANON MULTIPASS C3500	PHOTO	BC-22E
CANON MULTIPASS C5000	LARGE BLACK	BC-20
CANON MULTIPASS C5000	BLACK TANK	BCI-21B
CANON MULTIPASS C5000	COLOR TANK	BCI-21C
CANON MULTIPASS C5000	PHOTO	BC-22E

CANON P670	BLACK	BJI-642B
CANON S200/300	BLACK	BCI-24B
CANON S200/300	COLOR	BCI-24C
CANON S400/450/600	BLACK	BCI-3BK
CANON S400/450/600	CYAN	BCI-3C
CANON S400/450/600	MAGENTA	BCI-3M
CANON S400/450/600	PHOTO BLACK	BCI-3PBK
CANON S400/450/600	PHOTO CYAN	BCI-3PC
CANON S400/450/600	PHOTO MAGENTA	BCI-3PM
CANON S400/450/600	YELLOW	BCI-3Y
CANON S800/S820	BLACK	BCI-6BK
CANON S800/S820	CYAN	BCI-6C
CANON S800/S820	MAGENTA	BCI-6M
CANON S800/S820	PHOTO CYAN	BCI-6PC
CANON S800/S820	PHOTO MAGENTA	BCI-6PM
CANON S800/S820	YELLOW	BCI-6Y
COMPAQ		
COMPAQ A900 / A1000	BLACK	337709 OR LEXMARK 12A1970 NEW STYLE
COMPAQ A900 / A1000	COLOR	337710 OR LEXMARK 12A1980 UNIVERSAL OR NEW STYLE
COMPAQ A900 / A1000	PHOTO	337711 OR LEXMARK 12A1990
COMPAQ IJ200	BLACK	337714 OR LEXMARK 13400HC
COMPAQ IJ200	COLOR	337715 OR LEXMARK 13619HC
COMPAQ IJ300	BLACK	337709 OR LEXMARK 12A1970 NEW STYLE
COMPAQ IJ300	COLOR	337710 OR LEXMARK 12A1980 UNIVERSAL OR NEW STYLE
COMPAQ IJ600	BLACK	LEXMARK 17G0050
COMPAQ IJ600	COLOR	LEXMARK 17G0060
COMPAQ IJ650	BLACK	LEXMARK 17G0050
COMPAQ IJ650	COLOR	LEXMARK 17G0060
COMPAQ IJ700	BLACK	337709 OR LEXMARK 12A1970 NEW STYLE
COMPAQ IJ700	COLOR	337710 OR LEXMARK 12A1980 UNIVERSAL OR NEW STYLE
COMPAQ IJ750	BLACK	337709 OR LEXMARK 12A1970 NEW STYLE
COMPAQ IJ750	COLOR	337710 OR LEXMARK 12A1980 UNIVERSAL OR NEW STYLE
COMPAQ IJ750	PHOTO	337711 OR LEXMARK 12A1990
COMPAQ IJ900	BLACK	337709 OR LEXMARK 12A1970 NEW STYLE
COMPAQ IJ900	COLOR	337710 OR LEXMARK 12A1980 UNIVERSAL OR NEW STYLE
COMPAQ IJ900	PHOTO	337711 OR 12A1990
EPSON		
EPSON MJ-1000	BLACK	S020025
EPSON MJ-100V2	BLACK	S020025
EPSON MJ-1050	BLACK	S020025
EPSON MJ-1050V2	BLACK	S020025
EPSON MJ-1100	BLACK	S020025
EPSON MJ-450	BLACK	S020025
EPSON MJ-5000	BLACK	S020034
EPSON MJ-5000	COLOR	S020036
EPSON MJ-500C	BLACK	S020047
EPSON MJ-500V2	BLACK	S020025
EPSON MJ-5100C	BLACK	S020034
EPSON MJ-5100C	COLOR	S020036
EPSON MJ-510C	BLACK	S020047
EPSON MJ-510C	COLOR	S020097
EPSON MJ-700V	BLACK	S020034
EPSON MJ-700V	COLOR	S020036
EPSON MJ-700V2C	BLACK	S020034
EPSON MJ-700V2C	COLOR	S020036
EPSON MJ-8000C	BLACK	S020118
EPSON MJ-8000C	CYAN	S020130
EPSON MJ-8000C	MAGENTA	S020126
EPSON MJ-8000C	YELLOW	S020122

EPSON MJ-800C	BLACK	S020047
EPSON MJ-800C	COLOR	S020097
EPSON MJ-810C	BLACK	S020093
EPSON MJ-810C	COLOR	S020097
EPSON MJ-900C	BLACK	S020034
EPSON MJ-910C	BLACK	S020034
EPSON MJ-910C	COLOR	S020036
EPSON MJ-930C	BLACK	S020108
EPSON MJ-930C	COLOR	S020089
EPSON PM-2000C	PHOTO	S020110
EPSON PM-2000C	BLACK	S020093
EPSON PM-5000C	COLOR	S020118
EPSON PM-700	BLACK	S020093
EPSON PM-700	COLOR	S020110
EPSON SQ1170	PHOTO	S020110
EPSON STYLUS 1000	BLACK	S020025
EPSON STYLUS 1000 A3	BLACK	S020025
EPSON STYLUS 400	BLACK	S020025
EPSON STYLUS 800	BLACK	S020025
EPSON STYLUS 800+	BLACK	S020025
EPSON STYLUS C60	BLACK	T028201
EPSON STYLUS C60	COLOR	T029201
EPSON STYLUS C80	BLACK	T032120
EPSON STYLUS C80	CYAN	T032220
EPSON STYLUS C80	MAGENTA	T032320
EPSON STYLUS C80	YELLOW	T032420
EPSON STYLUS COLOR	BLACK	S020034
EPSON STYLUS COLOR	COLOR	S020036
EPSON STYLUS COLOR 1500	BLACK	S020062
EPSON STYLUS COLOR 1500	COLOR	S020049
EPSON STYLUS COLOR 1520	BLACK	S020108
EPSON STYLUS COLOR 1520	COLOR	S020089
EPSON STYLUS COLOR 200	BLACK	S020047
EPSON STYLUS COLOR 200	COLOR	S020097
EPSON STYLUS COLOR 3000	BLACK	S020118
EPSON STYLUS COLOR 3000	CYAN	S020130
EPSON STYLUS COLOR 3000	MAGENTA	S020126
EPSON STYLUS COLOR 3000	YELLOW	S020122
EPSON STYLUS COLOR 400	BLACK	S020093
EPSON STYLUS COLOR 400	COLOR	S020089
EPSON STYLUS COLOR 440	BLACK	S020187
EPSON STYLUS COLOR 480SX/580	BLACK	T013201
EPSON STYLUS COLOR 480SX/580	COLOR	T014201
EPSON STYLUS COLOR 440	COLOR	S020191
EPSON STYLUS COLOR 500	BLACK	S020093
EPSON STYLUS COLOR 500	COLOR	S020097
EPSON STYLUS COLOR 600	BLACK	S020093
EPSON STYLUS COLOR 600	COLOR	S020089
EPSON STYLUS COLOR 600Q	BLACK	S020093
EPSON STYLUS COLOR 600Q	COLOR	S020089
EPSON STYLUS COLOR 640	BLACK	S020187
EPSON STYLUS COLOR 640	COLOR	S020191
EPSON STYLUS COLOR 660 / 670	BLACK	S020189
EPSON STYLUS COLOR 660 / 670	COLOR	S020191
EPSON STYLUS COLOR 740	BLACK	S020189
EPSON STYLUS COLOR 740	COLOR	S020191
EPSON STYLUS COLOR 740I	BLACK	S020189
EPSON STYLUS COLOR 740I	COLOR	S020191
EPSON STYLUS COLOR 760	BLACK	S020189
EPSON STYLUS COLOR 760	COLOR	S020191
EPSON STYLUS COLOR 777	BLACK	T017201
EPSON STYLUS COLOR 777	COLOR	T018201
EPSON STYLUS COLOR 780	BLACK	T007201
EPSON STYLUS COLOR 780	COLOR	T008201

EPSON STYLUS COLOR 800	BLACK	S020108
EPSON STYLUS COLOR 800	COLOR	S020089
EPSON STYLUS COLOR 820	BLACK	T026201
EPSON STYLUS COLOR 820	COLOR	T027201
EPSON STYLUS COLOR 850	BLACK	S020108
EPSON STYLUS COLOR 850	COLOR	S020089
EPSON STYLUS COLOR 850N	BLACK	S020108
EPSON STYLUS COLOR 850N	COLOR	S020089
EPSON STYLUS COLOR 850NE	BLACK	S020108
EPSON STYLUS COLOR 850NE	COLOR	S020089
EPSON STYLUS COLOR 860	BLACK	S020189
EPSON STYLUS COLOR 860	COLOR	S020191
EPSON STYLUS COLOR 870/875/890	BLACK	T007201
EPSON STYLUS COLOR 870/875/890	COLOR	T008201
EPSON STYLUS COLOR 880	BLACK	T019201
EPSON STYLUS COLOR 880	COLOR	T020201
EPSON STYLUS COLOR 900	BLACK	T003011
EPSON STYLUS COLOR 900	COLOR	T005011
EPSON STYLUS COLOR 900N	BLACK	T003011
EPSON STYLUS COLOR 900N	COLOR	T005011
EPSON STYLUS COLOR 980	BLACK	T003011
EPSON STYLUS COLOR 980	COLOR	T005011
EPSON STYLUS COLOR 1160	BLACK	S020189
EPSON STYLUS COLOR 1160	COLOR	S020191
EPSON STYLUS COLOR 1270/1280	BLACK	T007201
EPSON STYLUS COLOR 1270/1280	COLOR	T009201
EPSON STYLUS COLOR C40/C40UX	BLACK	T013201
EPSON STYLUS COLOR C40/C40UX	COLOR	T014201
EPSON STYLUS COLOR II	BLACK	S020047
EPSON STYLUS COLOR II	COLOR	S020049
EPSON STYLUS COLOR IIS	BLACK	S020047
EPSON STYLUS COLOR IIS	COLOR	S020049
EPSON STYLUS COLOR PRO	BLACK	S020034
EPSON STYLUS COLOR PRO	COLOR	S020036
EPSON STYLUS COLOR PRO-XL	BLACK	S020034
EPSON STYLUS COLOR PRO-XL	COLOR	S020036
EPSON STYLUS COLOR PRO-XL PLUS	BLACK	S020034
EPSON STYLUS COLOR PRO-XL PLUS	COLOR	S020036
EPSON STYLUS PHOTO	COLOR	S020110
EPSON STYLUS PHOTO	BLACK	S020093
EPSON STYLUS PHOTO 1200	COLOR	T001011
EPSON STYLUS PHOTO 1200	BLACK	S020187
EPSON STYLUS PHOTO 1270	BLACK	T007201
EPSON STYLUS PHOTO 1270	COLOR	T009201
EPSON STYLUS PHOTO 2000P	COLOR	T016201
EPSON STYLUS PHOTO 2000P	BLACK	T015201
EPSON STYLUS PHOTO 700	COLOR	S020110
EPSON STYLUS PHOTO 700	BLACK	S020093
EPSON STYLUS PHOTO 750	COLOR	S020193
EPSON STYLUS PHOTO 750	BLACK	S020187
EPSON STYLUS PHOTO 870	BLACK	T007201
EPSON STYLUS PHOTO 870	COLOR	T008201
EPSON STYLUS PHOTO 875DC	BLACK	T007201
EPSON STYLUS PHOTO 875DC	COLOR	T008201
EPSON STYLUS PHOTO EX	COLOR	S020110
EPSON STYLUS PHOTO EX	BLACK	S020093
EPSON STYLUS PRO 5000	BLACK	S020118
EPSON STYLUS PRO 5000	CYAN	S020147
EPSON STYLUS PRO 5000	MAGENTA	S020143
EPSON STYLUS PRO 5000	YELLOW	S020122
EPSON STYLUS PRO 9000	BLACK	T407011
EPSON STYLUS PRO 9000	CYAN	T410011
EPSON STYLUS PRO 9000	LIGHT CYAN	T412011
EPSON STYLUS PRO 9000	LIGHT MAGENTA	T411011

EPSON STYLUS PRO 9000	MAGENTA	T409011
EPSON STYLUS PRO 9000	YELLOW	T408011
HP		
HP PROFESSIONAL 2000C SERIES	LARGE BLACK	C4844A HP#10
HP PROFESSIONAL 2000C SERIES	MAGENTA	C4843A HP#10
HP PROFESSIONAL 2000C SERIES	YELLOW	C4842A HP#10
HP PROFESSIONAL 2000C SERIES	CYAN	C4841A HP#10
HP 2227A (QUIETJET PLUS)	BLACK	51604A
HP 2228A (QUIETJET)	BLACK	51604A
HP 2276A	BLACK	51626A / G HP#26
HP BUSINESS 2000 SERIES	BLACK	C4844A HP#10
HP BUSINESS 2000 SERIES	MAGENTA	C4837A HP#11
HP BUSINESS 2000 SERIES	YELLOW	C4838A HP#11
HP BUSINESS 2000 SERIES	CYAN	C4836A HP#11
HP BUSINESS 2250 SERIES	BLACK	C4844A HP#10
HP BUSINESS 2250 SERIES	MAGENTA	C4837A HP#11
HP BUSINESS 2250 SERIES	YELLOW	C4838A HP#11
HP BUSINESS 2250 SERIES	CYAN	C4836A HP#11
HP BUSINESS 2500 SERIES	BLACK	C4844A HP#10
HP BUSINESS 2500 SERIES	MAGENTA	C4843A HP#10
HP BUSINESS 2500 SERIES	YELLOW	C4842A HP#10
HP BUSINESS 2500 SERIES	CYAN	C4841A HP#10
HP COLORCOPIER 110	BLACK	51645A / G HP#45
HP COLORCOPIER 110	COLOR	51641A HP#41
HP COLORCOPIER 120	BLACK	51645A / G HP#45
HP COLORCOPIER 120	COLOR	51641A HP#41
HP COPYJET/M	BLACK	51640A
HP COPYJET/M	CYAN	51640C
HP COPYJET/M	MAGENTA	51640M
HP COPYJET/M	YELLOW	51640Y
HP DESIGNJET 200	BLACK	51626A / G HP#26
HP DESIGNJET 220	BLACK	51626A / G HP#26
HP DESIGNJET 230	BLACK	51640A
HP DESIGNJET 250C	BLACK	51640A
HP DESIGNJET 250C	COLOR	51650C,M,Y
HP DESIGNJET 330	BLACK	51640A
HP DESIGNJET 350	BLACK	51640A
HP DESIGNJET 350	COLOR	51644C,M,Y
HP DESIGNJET 430	BLACK	51640A
HP DESIGNJET 450C	BLACK	51640A
HP DESIGNJET 450C	COLOR	51644C,M,Y
HP DESIGNJET 455CA	BLACK	51640A
HP DESIGNJET 455CA	COLOR	51644C,M,Y
HP DESIGNJET 488CA	BLACK	51640A
HP DESIGNJET 488CA	COLOR	51644C,M,Y
HP DESIGNJET 600	BLACK	51626A / G HP#26
HP DESIGNJET 650C/PS	BLACK	51640A
HP DESIGNJET 650C/PS	COLOR	51650C,M,Y
HP DESIGNJET 700	BLACK	51645A / G HP#45
HP DESIGNJET 750C/PLUS	BLACK	51645A / G HP#45
HP DESIGNJET 750C/PLUS	COLOR	51644C,M,Y
HP DESIGNJET 755CM	BLACK	51645A / G HP#45
HP DESIGNJET 755CM	COLOR	51644C,M,Y
HP DESKJET 1000 SERIES	BLACK	51645A / G HP#45
HP DESKJET 1000 SERIES	COLOR	51641A HP#41
HP DESKJET 1120C SERIES	BLACK	51645A / G HP#45
HP DESKJET 1120C SERIES	COLOR	C1823A / G / D HP#23
HP DESKJET 1200	BLACK	51640A
HP DESKJET 1200	COLOR	51640C,M,Y
HP DESKJET 1220C SERIES	BLACK	51645A / G HP#45
HP DESKJET 1220C SERIES	COLOR	C6578A / D HP#78
HP DESKJET 1600C	BLACK	51645A / G HP#45
HP DESKJET 1600C	COLOR	51640C,M,Y
HP DESKJET 300J PORTABLE	BLACK	51633M

HP DESKJET 310 / 320	BLACK	51626A
HP DESKJET 310 / 320	COLOR	51625A
HP DESKJET 340	BLACK	51626A
HP DESKJET 340	COLOR	51625A
HP DESKJET 350C / 350CBI	BLACK	C6628A HP#19
HP DESKJET 350C / 350CBI	COLOR	51649A / G HP#49
HP DESKJET 400	BLACK	51626A / G HP#26
HP DESKJET 400	COLOR	51625A HP#25
HP DESKJET 400L	BLACK	51626A / G HP#26
HP DESKJET 400L	COLOR	51625A HP#25
HP DESKJET 420C	BLACK	51626A / G HP#26
HP DESKJET 420C	COLOR	51625A HP#25
HP DESKJET 500 / 510 / 520	BLACK	51626A / G HP#26
HP DESKJET 540	BLACK	51626A / G HP#26
HP DESKJET 540	COLOR	51625A HP#25
HP DESKJET 550C / 560C / 560J	BLACK	51626A / G HP#26
HP DESKJET 550C / 560C / 560J	COLOR	51625A HP#25
HP DESKJET 600	BLACK	51629A / G HP#29
HP DESKJET 600	COLOR	51649A HP #49
HP DESKJET 610C	BLACK	C6614 HP #20
HP DESKJET 610C	COLOR	51649A HP#49
HP DESKJET 610C	PHOTO	C1816A HP#16
HP DESKJET 612C	BLACK	C6614 HP #20
HP DESKJET 612C	COLOR	51649A HP# 49
HP DESKJET 612C	PHOTO	C1816A HP#16
HP DESKJET 648C	BLACK	C6614 HP #20
HP DESKJET 648C	COLOR	51649A HP #49
HP DESKJET 648C	PHOTO	C1816A HP#16
HP DESKJET 660C	BLACK	51629A / G HP#29
HP DESKJET 660C	COLOR	51649A / G HP#49
HP DESKJET 670C	BLACK	51629A / G HP#29
HP DESKJET 670C	COLOR	51649A / G HP#49
HP DESKJET 672C	BLACK	51629A / G HP#29
HP DESKJET 672C	COLOR	51649A / G HP#49
HP DESKJET 680C / 682C	BLACK	51629A / G HP#29
HP DESKJET 680C / 652C	COLOR	51649A / G HP#49
HP DESKJET 690C	BLACK	51629A / G HP#29
HP DESKJET 690C	COLOR	51649A / G HP#49
HP DESKJET 690C	PHOTO	C1816A HP#16
HP DESKJET 692C	BLACK	51629A / G HP#29
HP DESKJET 692C	COLOR	51649A / G HP#49
HP DESKJET 692C	PHOTO	C1816A HP#16
HP DESKJET 693C	BLACK	51629A / G HP#29
HP DESKJET 693C	COLOR	51649A / G HP#49
HP DESKJET 693C	PHOTO	C1816A HP#16
HP DESKJET 694C	BLACK	51629A / G HP#29
HP DESKJET 694C	COLOR	51649A / G HP#49
HP DESKJET 694C	PHOTO	C1816A HP#16
HP DESKJET 695C	BLACK	51629A / G HP#29
HP DESKJET 695C	COLOR	51649A / G HP#49
HP DESKJET 695C	PHOTO	C1816A HP#16
HP DESKJET 697C	COLOR	51649A / G HP#49
HP DESKJET 697C	PHOTO	C1816A HP#16
HP DESKJET 697C	BLACK	51629A / G HP#29
HP DESKJET 710C	BLACK	51645A / G HP#45
HP DESKJET 710C	COLOR	C1823A / G / D HP#23
HP DESKJET 712C	BLACK	51645A / G HP#45
HP DESKJET 712C	COLOR	C1823A / G / D HP#23
HP DESKJET 720C	BLACK	51645A / G HP#45
HP DESKJET 720C	COLOR	C1823A / G / D HP#23
HP DESKJET 722C	BLACK	51645A / G HP#45
HP DESKJET 722C	COLOR	C1823A / G / D HP#23
HP DESKJET 810C	BLACK	C6615A HP #15
HP DESKJET 810C	COLOR	C1823A / G / D HP#23

HP DESKJET 812C	BLACK	C6615AN HP #15
HP DESKJET 812C	COLOR	C1823A / G / D HP# 23
HP DESKJET 815C	BLACK	51645A / G HP#45
HP DESKJET 815C	COLOR	C1823A / G / D HP#23
HP DESKJET 820C	BLACK	51645A / G HP#45
HP DESKJET 820C	COLOR	51641A HP#41
HP DESKJET 825C	BLACK	C6615A HP#15
HP DESKJET 825C	COLOR	C6625A HP#17
HP DESKJET 830/832	BLACK	51645A HP# 45
HP DESKJET 830/832	COLOR	C1823A/D/G HP#23
HP DESKJET 840C	BLACK	C6615A HP #15
HP DESKJET 840C	COLOR	C6625AN HP#17
HP DESKJET 842C / 843C / 845C	BLACK	C6615A HP #15
HP DESKJET 842C / 843C / 845C	COLOR	C6625AN HP#17
HP DESKJET 850C	BLACK	51645A / G HP#45
HP DESKJET 850C	COLOR	51641A HP#41
HP DESKJET 855C	BLACK	51645A / G HP#45
HP DESKJET 855C	COLOR	51641A HP#41
HP DESKJET 870C	BLACK	51645A / G HP#45
HP DESKJET 870C	COLOR	51641A HP#41
HP DESKJET 870CSE	BLACK	51645A / G HP#45
HP DESKJET 870CSE	COLOR	51641A
HP DESKJET 870CXI	BLACK	51645A / G
HP DESKJET 870CXI	COLOR	51641A
HP DESKJET 880C	BLACK	51645A / G
HP DESKJET 880C	COLOR	C1823A / G / D
HP DESKJET 882C	BLACK	51645A / G
HP DESKJET 882C	COLOR	C1823A / G / D
HP DESKJET 890C	BLACK	51645A / G
HP DESKJET 890C	COLOR	C1823A / G / D
HP DESKJET 895C	BLACK	51645A / G
HP DESKJET 895C	COLOR	C1823A / G / D
HP DESKJET 920C/ CXI/ CVR	BLACK	C6615A HP#15
HP DESKJET 920C/ CXI/ CVR	COLOR	C6578A HP#78
HP DESKJET 930	BLACK	51645A / G HP#45
HP DESKJET 930	COLOR	C6578A/ D / G HP#78
HP DESKJET 932	BLACK	51645A / G HP#45
HP DESKJET 932	COLOR	C6578A/ D / G HP#78
HP DESKJET 935C	BLACK	51645A / G HP#45
HP DESKJET 935C	COLOR	C6578A/ D / G HP#78
HP DESKJET 940C / CVR	BLACK	C6615A HP#15
HP DESKJET 940C / CVR	COLOR	C6578A HP#78
HP DESKJET 950	BLACK	51645A / G HP#45
HP DESKJET 950	COLOR	C6578A/ D / G HP#78
HP DESKJET 952	BLACK	51645A / G HP#45
HP DESKJET 952	COLOR	C6578A/ D / G HP#78
HP DESKJET 955	BLACK	51645A / G HP#45
HP DESKJET 955	COLOR	C6578A/ D / G HP#78
HP DESKJET 959	BLACK	51645A / G HP#45
HP DESKJET 959	COLOR	C6578A/ D / G HP#78
HP DESKJET 960C SERIES	BLACK	51645A / G HP#45
HP DESKJET 960C SERIES	COLOR	C6578A/ D / G HP#78
HP DESKJET 970C SERIES	BLACK	51645A / G HP#45
HP DESKJET 970C SERIES	COLOR	C6578A/ D / G HP#78
HP DESKJET 980C SERIES	BLACK	51645A / G HP#45
HP DESKJET 980C SERIES	COLOR	C6578A/ D / G HP#78
HP DESKJET 990C SERIES	BLACK	51645A / G HP#45
HP DESKJET 990C SERIES	COLOR	C6578A/ D / G HP#78
HP DESKJET	BLACK	51626A / G HP#26
HP DESKJET PLUS	BLACK	51626A / G HP#26
HP DESKWRITER 310	BLACK	51633M
HP DESKWRITER 310	COLOR	51625A
HP DESKWRITER 520	BLACK	51626A / G
HP DESKWRITER 540	BLACK	51626A / G

HP DESKWRITER 540	COLOR	51625A
HP DESKWRITER 550C	BLACK	51626A / G
HP DESKWRITER 550C	COLOR	51625A
HP DESKWRITER 600	BLACK	51629A / G
HP DESKWRITER 600	COLOR	51649A / G
HP DESKWRITER 660C	BLACK	51629A / G
HP DESKWRITER 660C	COLOR	51649A / G
HP DESKWRITER 680C	BLACK	51629A / G
HP DESKWRITER 680C	COLOR	51649A / G
HP DESKWRITER	BLACK	51626A / G
HP DESKWRITER	BLACK	51626A / G
HP DESKWRITER	COLOR	51625A
HP FAX	BLACK	51626A / G HP#26
HP FAX 200	BLACK	51626A / G HP#26
HP FAX 300 / 310	BLACK	51626A / G HP#26
HP FAX 700	BLACK	51626A / G HP#26
HP FAX 750	BLACK	51626A / G HP#26
HP FAX 900	BLACK	51629A / G HP#29
HP FAX 950	BLACK	51629A / G HP#29
HP OFFICEJET	BLACK	51626A / G HP#26
HP OFFICEJET 300	BLACK	51626A / G HP#26
HP OFFICEJET 500	BLACK	51629A / G HP#29
HP OFFICEJET 500	COLOR	51649A HP#49
HP OFFICEJET 520	BLACK	51629A / G HP#29
HP OFFICEJET 520	COLOR	51649A HP#49
HP OFFICEJET 570	BLACK	51629A / G HP#29
HP OFFICEJET 570	COLOR	51649A HP#49
HP OFFICEJET 580	BLACK	51629A / G HP#29
HP OFFICEJET 580	COLOR	51649A HP#49
HP OFFICEJET 590	BLACK	51629A / G HP#29
HP OFFICEJET 590	COLOR	51649A HP#49
HP OFFICEJET 600	BLACK	51629A / G HP#29
HP OFFICEJET 600	COLOR	51649A HP#49
HP OFFICEJET 610	BLACK	51629A / G HP#29
HP OFFICEJET 610	COLOR	51649A HP#49
HP OFFICEJET 610	COLOR	51649A HP#49
HP OFFICEJET 630	BLACK	51629A / G HP#29
HP OFFICEJET 630	COLOR	51649A HP#49
HP OFFICEJET 700	BLACK	51629A / G HP#29
HP OFFICEJET 700	COLOR	51649A HP#49
HP OFFICEJET 700	PHOTO	C1816A HP#16
HP OFFICEJET 710	BLACK	51629A / G HP#29
HP OFFICEJET 710	COLOR	51649A HP#49
HP OFFICEJET 710	PHOTO	C1816A HP#16
HP OFFICEJET 720	BLACK	51629A / G HP#29
HP OFFICEJET 720	COLOR	51649A HP#49
HP OFFICEJET 720	PHOTO	C1816A HP#16
HP OFFICEJET G SERIES	BLACK	51645A / G HP#45
HP OFFICEJET G SERIES	COLOR	C6578A/ D HP#78
HP OFFICEJET K SERIES	BLACK	51645A / G HP#45
HP OFFICEJET K SERIES	COLOR	C6578A/ D HP#78
HP OFFICEJET LX	BLACK	51626A / G HP#26
HP OFFICEJET MFP	BLACK	51626A / G HP#26
HP OFFICEJET PERSONAL	BLACK	51626A / G HP#26
HP OFFICEJET PRO 1150	BLACK	51645A / G HP#45
HP OFFICEJET PRO 1150	COLOR	51641A HP#41
HP OFFICEJET PRO	BLACK	51645A / G HP#45
HP OFFICEJET PRO	COLOR	51641A HP#41
HP OFFICEJET PRO 1170 CXI	BLACK	51645A / G HP#45
HP OFFICEJET PRO 1170 CXI	COLOR	C1823A / G / D HP#23
HP OFFICEJET PRO 1175 CXI	BLACK	51645A / G HP#45
HP OFFICEJET PRO 1175 CXI	COLOR	C1823A / G / D HP#23
HP OFFICEJET R40 / 60+ / 80 / 80XI	BLACK	51645A / G HP#45
HP OFFICEJET R40 / 60+ / 80 / 80XI	COLOR	C1823A / D / G HP#23
HP OFFICEJET T45	BLACK	51645A / G HP#45

HP OFFICEJET T45	COLOR	C1823A / D / G HP#23
HP OFFICEJET T65	BLACK	51645A / G HP#45
HP OFFICEJET T65	COLOR	C1823A / D / G HP#23
HP PHOTOSMART 100	COLOR	C6657A HP#57
HP PHOTOSMART P1000 / P1100 SERIES	BLACK	51645A / G HP#45
HP PHOTOSMART P1000 / P1100 SERIES	COLOR	C6578A/ D HP#78
HP PHOTOSMART 1200/1300 SERIES	BLACK	51645A/G HP#45
HP PHOTOSMART 1200/1300 SERIES	COLOR	C6578A/D HP#78
HP PRINTER/SCANNER/COPIER 370	BLACK	51629A / G HP#29
HP PRINTER/SCANNER/COPIER 370	COLOR	51649A HP#49
HP PRINTER/SCANNER/COPIER 370	PHOTO	C1816A HP#16
HP PRINTER/SCANNER/COPIER 380	BLACK	51629A / G HP#29
HP PRINTER/SCANNER/COPIER 380	COLOR	51649A HP#49
HP PRINTER/SCANNER/COPIER 380	PHOTO	C1816A HP#16
HP PSC 500	BLACK	C6615A HP #15
HP PSC 500	COLOR	C1823A / G / D HP#23
LEXMARK		
LEXMARK 1000	BLACK	1361400 / 13400HC
LEXMARK 1000	COLOR	1380619 / 13619HC
LEXMARK 1020	BLACK	1361400 / 13400HC
LEXMARK 1020	COLOR	1380619 / 13619HC
LEXMARK 1100	BLACK	1361400 / 13400HC
LEXMARK 1100	COLOR	1380619 / 13619HC
LEXMARK 2030	BLACK	1361400 / 13400HC
LEXMARK 2030	COLOR	1380619 / 13619HC
LEXMARK 2030	PHOTO	1361760
LEXMARK 2050	BLACK	1361400 / 13400HC
LEXMARK 2050	COLOR	1380619 / 13619HC
LEXMARK 2050	PHOTO	1361760
LEXMARK 2055	BLACK	1361400 / 13400HC
LEXMARK 2055	COLOR	1380619 / 13619HC
LEXMARK 2055	PHOTO	1361760
LEXMARK 2070	BLACK	1382050
LEXMARK 2070	COLOR	1382060
LEXMARK 3000	BLACK	1361400 / 13400HC
LEXMARK 3000	COLOR	1380619 / 13619HC
LEXMARK 3000	PHOTO	1361760
LEXMARK 7000	BLACK	12A1970 / 75
LEXMARK 7000	COLOR	12A1980 / 85
LEXMARK 7200/V	BLACK	12A1970 / 75
LEXMARK 7200/V	COLOR	12A1980 / 85
LEXMARK EXECJET 4076	BLACK	1361400 / 13400HC
LEXMARK EXECJET 4076	COLOR	1380619 / 13619HC
LEXMARK EXECJET IIC	BLACK	1361400 / 13400HC
LEXMARK EXECJET IIC	COLOR	1380619 / 13619HC
LEXMARK JETPRINTER 3200	BLACK	12A1970 / 75
LEXMARK JETPRINTER 3200	COLOR	12A1980 / 85
LEXMARK JETPRINTER 3200	PHOTO	12A1990
LEXMARK JETPRINTER 5700	BLACK	12A1970 / 75
LEXMARK JETPRINTER 5700	COLOR	12A1980 / 85
LEXMARK JETPRINTER 5700	PHOTO	12A1990
LEXMARK JETPRINTER 5770	BLACK	12A1970 / 75
LEXMARK JETPRINTER 5770	COLOR	12A1980 / 85
LEXMARK JETPRINTER 5770	PHOTO	12A1990
LEXMARK JETPRINTER 7200	BLACK	12A1970 / 75
LEXMARK JETPRINTER 7200	COLOR	12A1980 / 85
LEXMARK JETPRINTER 7200	PHOTO	12A1990
LEXMARK JETPRINTER 7200V	BLACK	12A1970 / 75
LEXMARK JETPRINTER 7200V	COLOR	12A1980 / 85
LEXMARK JETPRINTER 7200V	PHOTO	12A1990
LEXMARK Z11	BLACK	12A1970 / 75
LEXMARK Z11	COLOR	12A1980 / 85
LEXMARK Z12	BLACK	17G0050 / 55
LEXMARK Z12	COLOR	17G0060 / 65

LEXMARK Z13	BLACK	10N0016
LEXMARK Z13	COLOR	10N0026
LEXMARK Z22 / Z32	BLACK	17G0050 / 55
LEXMARK Z22 / Z32	COLOR	17G0060 / 65
LEXMARK Z22 / Z32	PHOTO	12A1990
LEXMARK Z23	BLACK	10N0016
LEXMARK Z23	COLOR	10N0026
LEXMARK Z31	BLACK	12A1970 / 75
LEXMARK Z31	COLOR	12A1980 / 85
LEXMARK Z33	BLACK	10N0016
LEXMARK Z33	COLOR	10N0026
LEXMARK Z42 / Z43 / Z51 / Z52 / Z53 / Z82	BLACK	12A1970 / 75
LEXMARK Z42 / Z43 / Z51 / Z52 / Z53 / Z82	COLOR	15M0120 / 125
LEXMARK MEDLEY SERIES	BLACK	1361400 / 13400HC
LEXMARK MEDLEY SERIES	COLOR	1380619 / 13619HC
LEXMARK OPTRA COLOR 40	BLACK	12A1970 / 75
LEXMARK OPTRA COLOR 40	COLOR	12A1980 / 85
LEXMARK OPTRA COLOR 40	PHOTO	12A1990
LEXMARK OPTRA COLOR 45	BLACK	12A1970 / 75
LEXMARK OPTRA COLOR 45	COLOR	12A1980 / 85
LEXMARK OPTRA COLOR 45	PHOTO	12A1990
LEXMARK WINWRITER 150C	BLACK	1361400 / 13400HC
LEXMARK WINWRITER 150C	COLOR	1380619 / 13619HC
XEROX		
XEROX C20	BLACK	8R7881
XEROX C20	COLOR	8R7880
XEROX DOCUPRINT C11	BLACK	8R7903
XEROX DOCUPRINT C11	COLOR	8R7904
XEROX DOCUPRINT C15	BLACK	8R7903
XEROX DOCUPRINT C15	COLOR	8R7904
XEROX DOCUPRINT C6	BLACK	8R7660
XEROX DOCUPRINT C6	LARGE BLACK	8R7638
XEROX DOCUPRINT C6	CYAN	8R7661
XEROX DOCUPRINT C6	MAGENTA	8R7662
XEROX DOCUPRINT C6	YELLOW	8R7663
XEROX DOCUPRINT C8	BLACK	8R7660
XEROX DOCUPRINT C8	LARGE BLACK	8R7638
XEROX DOCUPRINT C8	CYAN	8R7661
XEROX DOCUPRINT C8	MAGENTA	8R7662
XEROX DOCUPRINT C8	YELLOW	8R7663
XEROX NC20	BLACK	8R7881
XEROX NC20	COLOR	8R7880
XEROX NC20	PHOTO	8R7883
XEROX WORKCENTRE 450C	BLACK	8R7660
XEROX WORKCENTRE 450C	LARGE BLACK	8R7638
XEROX WORKCENTRE 450C	CYAN	8R7661
XEROX WORKCENTRE 450C	MAGENTA	8R7662
XEROX WORKCENTRE 450C	YELLOW	8R7663
XEROX WORKCENTRE 470CX	BLACK	8R7881
XEROX WORKCENTRE 470CX	COLOR	8R7880
XEROX WORKCENTRE 470CX	PHOTO	8R7883
XEROX WORKCENTRE 480C	BLACK	8R7881
XEROX WORKCENTRE 480C	COLOR	8R7880
XEROX WORKCENTRE 480C	PHOTO	8R7883
XEROX WORKCENTRE XI70C	BLACK	8R7903
XEROX WORKCENTRE XI70C	COLOR	8R7904
XEROX XJ4C	BLACK	8R7660
XEROX XJ4C	LARGE BLACK	8R7638
XEROX XJ4C	CYAN	8R7661
XEROX XJ4C	MAGENTA	8R7662
XEROX XJ4C	YELLOW	8R7663
XEROX XJ6C	BLACK	8R7660

XEROX XJ6C	LARGE BLACK	8R7638
XEROX XJ6C	CYAN	8R7661
XEROX XJ6C	MAGENTA	8R7662
XEROX XJ6C	YELLOW	8R7663
XEROX XJ8C	BLACK	8R7881
XEROX XJ8C	COLOR	8R7880
XEROX XJ8C	PHOTO	8R7883
XEROX XJ9C	BLACK	8R7881
XEROX XJ9C	COLOR	8R7880
XEROX XJ9C	PHOTO	8R7883
XEROX XK35C	BLACK	8R7881
XEROX XK35C	BLACK	8R7879 / 881
XEROX XK35C	COLOR	8R12591